

WOOD MAINTENANCE INSTRUCTIONS

ROUTINE CLEANING

Vacuum clean using parquet brush.

Clean with a neutral detergent suitable for painted wooden floors, diluted in water according to the manufacturer's instructions, using a well-wrung cloth (preferably cotton).

BATHROOMS

After using the shower and/or bath or any other devices that create a high level of humidity, air the room to restore the correct environmental conditions. Failure to do this means that over time the floor may be damaged beyond repair.

KITCHENS

Promptly remove the most damaging kind of soiling (tomato sauce, red and white wine, coffee, oil, alcohol, aggressive detergents such as bleach, ammonia, limescale remover, vinegar) with a damp, non-abrasive cloth without rubbing. If cooking causes alterations in the temperature and humidity conditions, restore the right conditions by airing the room well.

PERIODICAL CLEANING

Three/four times a year, after cleaning the floor as described above and waiting until completely dry, polish with wax diluted 1:10 (1 part wax and 10 parts water) using a cotton cloth.

If the floor is of the SUGAR colour, we recommend using a detergent and polish containing white pigments.

IMPORTANT: NEVER USE STEAM-CLEANING DEVICES

RECOMMENDED PRODUCTS

Routine cleaning: Fila Cleaner

Periodical cleaning: Fila Parquet Wax